

BOSCH

WASHING MACHINE ERROR CODES



شرکت مازندپلاست نور
www.mpn101.com

Bosch Logixx WAS Series Washing Machine Error Codes

F16= Door lock error پیغام خطای درب

F17= Inlet valve error detected ایراد ورودی آب

F18= Drain error detected پمپ تخلیه عمل نمیکند

F23= Anti flood device has been activated پیغام خطای سوئیچ شناور کف

F34= Door lock error پیغام خطای میکرو سوئیچ درب

F42= Motor fault موتور-ذغال موتور- سوکت-سیم کشی

F43= Motor fault موتور-ذغال موتور- سوکت- سیم کشی

F44= Motor fault موتور-ذغال موتور- سوکت- سیم کشی

Bosch WAE Range Washing Machine Fault Codes

F16= Door lock problem

F17= Inlet valve

F18= Drain pump

F21= Motor

F23= Anti flood system activated

Bosch WFP Range Washing Machine Fault Codes

F01= Water intake timeout

F02= Heating timeout

F03= Draining timeout

F04= Motor fault

F05= Uncontrolled motor startup

F06= Short on NTC Detected on hot water intake

F07= Open circuit NTC Open circuit wiring

F08= Door open when program started

F09= Unexpected heating

F10= Communication error

F11= Overheating

F12= Short circuit اشکال در برد

F13= Mains voltage too high

F14= Mains voltage too low

F15=Faulty temperature sensor on motor PCB

F16= Faulty rinse sensor Displayed only in test

